In car entertainment

Audio

CD changer range

• Range of high quality CD changers, uniquely designed for Nissan.

· All units come with a three year warranty.

• For a number of vehicles the NE audio range has been included in the Whole Vehicle Type Approval (WVTA). This procedure makes our range avaible for Port Installation (P.I.) activities.

specific Install ation kits stal

Description	Part Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	S.O.S.
CD autochanger CV747	B8183-89901	9	L	S6#	MX	238.30	09/'97

6 CD cartridge for continuous play.

Size: 225 x 63 x 167.

 C-Bus CD-Management. Extra cartridge available separately (part number B8118-89900). Positioning under any angle. 3-beam laser
 8x oversampling
 CD singles
 Advanced shock free system • This unit replaces the old type C-Bus CD changer: CV95B (B8182-C9910) Application Fitting Time Until Countries From Remarks K10 All Connects to: CH907 30 C-bus K11E All · Connects to: CH907 30 C-bus Connects to: CH907 B11 All 30 --C-bus B12 All Connects to: CH907 30 -C-bus N10 All Connects to: CH907 30 _ C-bus N12 All Connects to: CH907 30 -C-bus N13 All Connects to: CH907 30 C-bus N14 All Connects to: CH907 30 -C-bus N15 Connects to: CH907 All -30 -N16(E) Connects to: CH907 All 30 -C-bus Y10 All Connects to: CH907 30 -C-bus B13 All Connects to: CH907 30 Connects to: CH907 T11 All 30 . -C-bus T12 All · Connects to: CH907 30 -C-bus T72 All Connects to: CH907 30 --C-bus U11 All Connects to: CH907 30 C-bus P10E All Connects to: CH907 30 . -C-bus P11E All Connects to: CH907 30 C-bus W10 All • Connects to: CH907 30 --C-bus **WP11** All Connects to: CH907 30 --• Brackets: 28195-8F805, 28195-8F810 & 28196-8F810 C31 All Connects to: CH907 30 -C-bus C32 Connects to: CH907 30 All C-bus J30 All Connects to: CH907 30 --C-bus A32 All Connects to: CH907 30 C-bus CA33 All Connects to: CH907 30 _ -C-bus M10 All Connects to: CH907 30 -C-bus M11 All -• Connects to: CH907 30 C-bus



All

All

All

C23M

D21

D22

_

-

Connects to: CH907

Connects to: CH907

Connects to: CH907

C-bus

C-bus

C-bus

30

30

30

In car entertainment

Audio

Application	Countries	From	Until	Remarks	Fitting Time
160	All	-	-	• Connects to: CH907 C-bus	30
260	All	-	-	• Connects to: CH907 C-bus	30
Y60	All	-	-	• Connects to: CH907 C-bus	30
Y61	All	-	-	• Connects to: CH907 C-bus	30
R20	All	-	-	• Connects to: CH907 C-bus	30
Т30	All	06/'01	-	Connects to: CH907 • C-bus	30
WD21	All	-	-	Connects to: CH907 C-bus	30
R50	All	-	-	• Connects to: CH907 C-bus	30
S12	All	-	-	• Connects to: CH907 C-bus	30
S13	All	-	-	• Connects to: CH907 C-bus	30
S14	All	-	-	• Connects to: CH907 C-bus	30
Z31	All	-	-	• Connects to: CH907 C-bus	30
Z32	All	-	-	• Connects to: CH907 C-bus	30
E23	All	-	-	• Connects to: CH907 C-bus	30
E24	All	-	-	• Connects to: CH907 C-bus	30
C120	All	-	-	• Connects to: CH907 C-bus	30
C220	All	-	-	• Connects to: CH907 C-bus	30
GC22	All	-	-	• Connects to: CH907 C-bus	30
HC23M	All	-	-	• Connects to: CH907 C-bus	30
F22	All	-	-	• Connects to: CH907 C-bus	30
F23	All	-	-	• Connects to: CH907 C-bus	30
TL0	All	-	-	• Connects to: CH907 C-bus	30
Trade 75	All	-	-	• Connects to: CH907 C-bus	30
Trade 100	All	-	-	• Connects to: CH907 C-bus	30
Trade 375	All	-	-	• Connects to: CH907 C-bus	30
Trade 314	All	-	-	• Connects to: CH907 C-bus	30
ТКО	All	-	-	• Connects to: CH907 C-bus	30
ECO-T.085	All	-	-	• Connects to: CH907 C-bus	30
ECO-T.100	All	-	-	• Connects to: CH907 C-bus	30
ECO-T.135	All	-	-	• Connects to: CH907 C-bus	30
ECO-T.160	All	-	-	• Connects to: CH907 C-bus	30
ECO-T.200	All	-	-	• Connects to: CH907 C-bus	30
L35	All	-	-	• Connects to: CH907 C-bus	30
L45	All	-	-	• Connects to: CH907 C-bus	30
L60	All	-	-	• Connects to: CH907 C-bus	30
L70	All	-	-	• Connects to: CH907 C-bus	30
L75/7D	All	-	-	• Connects to: CH907 C-bus	30
L80	All	-	-	• Connects to: CH907 C-bus	30

In car entertainment

Application	Countries	From	Until	Remarks	Fitting Time					
L90	All	-		Connects C-bus	30					
M110	All	-		• Connects to: CH907 C-bus					30	
M115	All	-		• Connects to: CH907 C-bus					30	
M115/8D	All	-		Connects to: CH907 C-bus					30	
M130	All	-		Connects C-bus	30					
M140	All	-		- • Connects to: CH907 C-bus						
Description		Part	Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	S.O.S.	
CD autochanger CV707		B818	4-89960	9	L	S6#	JP	228.30	09/'99	

• 6 CD cartridge for continuous play

Size: 225 x 63 x 167
N-Bus CD-Management

• Extra CD-cartridge available separately (part number B8118-89900)

Positioning under any angle

• 3-beam laser • 8x oversampling • CD singles • Advanced shock free system
 • This unit has replaced the CV715.

Application	Countries	From	Until	Remarks	Fitting Tim
K10	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
K11E	All	08/'92	07/'00	Connects to: CK926 / CK936 / specific factory audio units.	30
B11	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
B12	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
N10	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
N12	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
N13	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
N14	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
N15	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
N16(E)	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
Y10	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
B13	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
T11	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
T12	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
T72	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
U11	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30
P10E	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
P11E	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
W10	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
WP11	All	-	-	Connects to: CK926 / CK936 / specific factory audio units. Brackets: 28195-8F805, 28195-8F810 & 28196-8F810	30
C31	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
C32	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
J30	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
A32	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
CA33	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
M10	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
M11	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
V10M	All	-	-	Connects to: CK926, CK936 & Integrated (audio) Radio/cassette player.	30
C23M	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
D21	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
D22	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
160	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
260	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
Y60	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
Y61	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
R20	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
Т30	All	06/'01	-	Connects to: CK926 / CK936 / specific factory audio units. N-bus harness P# B8377-89962 not included!	30
WD21	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
R50	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
S12	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
S13	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
S14	All	-	-	• Connects to: CK926 / CK936 / specific factory audio units.	30
Z31	All	-	-	Connects to: CK926 / CK936 / specific factory audio units.	30



Audio

Audio

In car entertainment

Application	Countries	From	Until	Remarks			_		Fitting Time
Z32	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
E23	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
E24	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
C120	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
C220	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
GC22	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
HC23M	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
F22	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
F23	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
TL0	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
Trade 75	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
Trade 100	All	-	-	• Connects	to: CK92	6 / CK93	6 / specifi	ic factory audio units	. 30
Trade 375	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
Trade 314	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ТКО	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ECO-T.085	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ECO-T.100	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ECO-T.135	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ECO-T.160	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
ECO-T.200	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L35	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L45	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L60	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L70	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L75/7D	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L80	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
L90	All	-	-	Connects	to: CK92	6 / CK93	6 / specifi	ic factory audio units	. 30
M110	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
M115	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
M115/8D	All	-	-	• Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
M130	All	-	-	Connects	to: CK92	6 / CK93	6 / specifi	ic factory audio units	. 30
M140	All	-	-	Connects	to: CK92	26 / CK93	6 / specifi	ic factory audio units	. 30
Description		Part	Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	S.O.S.
In-dash CD changer			4-89961	1	L	SR6	JP	344.15	01/'00



Application	Countries	From	Until	Remarks	Fitting Time
N16(E)	All	01/'00	-	In C-cluster Screw required for fitting 01422-00031	20
CA33	All	01/'00	-	In C-cluster Screw required for fitting 01422-00031	20